

FIGURE 1




FIGURE 2

200

Diagram illustrating the frequency ranges for various channels, categorized by common use. The table is bounded by a large bracket on the left and three brackets on the right, labeled 200, 202, 204, 206, and 208.

Channel	Frequency Range	Common Use
T7	5.75 – 11.75	Data
T8	11.75 – 17.75	
T9	17.75 – 23.75	
T10	23.75 – 29.75	
T11	29.75 – 35.75	
T12	35.75 – 41.75	
T13	41.75 – 47.75	
2	54.0 – 60.0	Television Service Channels
3	60.0 – 66.0	
4	66.0 – 72.0	
5	76.0 – 82.0	
6	82.0 – 88.0	
7	174.0 – 180.0	
8	180.0 – 186.0	
9	186.0 – 192.0	
10	192.0 – 198.0	
11	198.0 – 204.0	
12	204.0 – 210.0	
13	210.0 – 216	
FM	88.0 – 108.0	Radio
14-22	120.0 – 174.0	Television Service Channels
23- 158	216.0 – 1002.0	

FIGURE 3




FIGURE 4




FIGURE 1




FIGURE 2

200

Channel	Frequency Range	Common Use
T7	5.75 – 11.75	Data
T8	11.75 – 17.75	
T9	17.75 – 23.75	
T10	23.75 – 29.75	
T11	29.75 – 35.75	
T12	35.75 – 41.75	
T13	41.75 – 47.75	
2	54.0 – 60.0	Television Service Channels
3	60.0 – 66.0	
4	66.0 – 72.0	
5	76.0 – 82.0	
6	82.0 – 88.0	
7	174.0 – 180.0	
8	180.0 – 186.0	
9	186.0 – 192.0	
10	192.0 – 198.0	
11	198.0 – 204.0	
12	204.0 – 210.0	
13	210.0 – 216	
FM	88.0 – 108.0	Radio
14-22	120.0 – 174.0	Television Service Channels
23- 158	216.0 – 1002.0	

FIGURE 3




FIGURE 4

